


Zeiss LSM 510 META user manual

Hege Avsnes Dale, Molecular Imaging Center, UiB



Open the LSM software in expert mode



The software opens like this:



OBS! Before looking at the sample in the microscope press the VIS button.

For regular imaging you need the 4 first windows in the acquire menu (marked red).

The screenshot displays the LSM 510 Expert Mode software interface. The 'Acquire' menu is highlighted in red, and four sub-items are also highlighted in red: 'Laser', 'Micro', 'Config', and 'Scan'. Arrows point from these sub-items to their respective control panels: 'Laser' to the Laser Control panel, 'Micro' to the Configuration Control panel, 'Config' to the Beam Path and Channel Assignment panel, and 'Scan' to the Scan Control panel.

Laser Control Panel:

Laser Unit	Wavelength	Power
Laser Diode 405	405 nm	On
Argon/2	458, 477, 488, 514 nm	Stdy
HeNe1	543 nm	On
HeNe2	633 nm	Off

Argon/2 settings:
Maximum Power: 30.0 mW
Wavelength: 458, 477, 488, 514 nm
Status: Ready
Tube Current: 3.3 A
Output [%]: 25

Configuration Control Panel:

Channel Mode: Lambda Mode Online Fingerprinting
Single Track Multi Track Ratio
of Tracks
Switch tracks after each: Line Frame Frame Fast
Name Channels Light (nm)
[x] Track Ch2
Add Track Remove Store/Apply Single Track

Beam Path and Channel Assignment Panel:

LSM 510 Camera
None LP 420 Ch2
None LP 505 Ch3
Mirror
NT 80/20
Excitation
Specimen ChD

Scan Control Panel:

Mode Channels Z Settings
Spot Line Frame Use ROI Z Stack
Objective Lens, Image Size & Line Step Factor
Objective: Plan-Apochromat 63x/1.4 Oil DIC
Frame Size: 128 256 512 1024 2048
Optimal X: 512 Y: 512 Line Step: 1
Speed
Scan Speed: 9 Pixel Time: 1.60 µsec Scan Time: 983.04 msec
Pixel Depth, Scan Direction & Scan Average
Data Depth: 8 Bit 12 Bit Mode: Line
Method: Mean
Scan Direction: Scan Average: Number: 1
Zoom, Rotation & Offset
Zoom: 1 Rotation: 0
Offset X: 0.00 µm Offset Y: 0.00 µm

Content of this user manual:

1. Changing objective.....p 5
2. Switching on and off lasers.....p 6
3. Setting up configurations for sequential scanning.....p 7-11
4. Adjusting the pinhole.....p 12
5. Optimization and acquisition of a multicolored image.....p 13-21
6. Acquisition of a Z-stack.....p 22-24
7. Saving the images.....p 25-26
8. Setting up for DIC (transmission) imaging.....p 27-30
9. Time series.....p 31-32

1. Changing objectives

Microscope Control allows you to control the microscope from the software.

But these settings are most of the time more natural to do on the microscope.


Except from:

Changing objectives

It's easier in the software to see which objectives are in the revolver and their position.

Prevents changing from oil- to air-objectives by accident...

OBS: Changing objectives in the revolver must be registered in the software (File menu; maintain; objectives), if not all the settings will relate to the objectives the software "thinks" are in.



2. Switching on and off lasers



Switch only on the lasers you need!
If lasers are on when you start, switch off the ones you're not using.

The lasers have different power ranging from 1 to 30 mW.

The Argon laser is the strongest laser and has its own output (%) slider in the laser control window. It is turned on in standby. When status comes up as ready it can be switched on. Never work in standby and always use 40 % output as a starting point.

Turning on this laser automatically starts a fan. When turning off the fan automatically stops after a while and until it stops the remote control must not be switched off!

All other lasers are only switched on and off and has no fan.



3. Setting up configurations for sequential scanning

Setting up a configuration for 3 colors, blue, green and red in “Configuration control”.

Always start in Channel Mode and Multi Track.

Each color is set up in a separate track → sequential scanning.


The procedure step by step for each track (color):

- 1) Under excitation activate the laser and choose a transmission %.
- 2) Choose the main beam splitter (HFT), which will direct the laser light to your sample.
- 3) Choose the correct beam splitters/mirrors (NFT) for the emission to be directed to the chosen detector (ChS/2/3).
- 4) Choose the correct emission filter.
- 5) Activate the detector (Ch) and define the color on the channel.

See details in the next pages.

HFT = Haupt Farb Tailer → The numbers indicate which laser is reflected towards the sample.

NFT = Neben Farb Tailer → The number indicate where the light is split, ex. NFT490; all light below 490 nm is reflected, and light above 490 nm passes through.



1

Activate laser (only one for each track).

Remember to turn on laser in Laser Control.

Choose transmission %.

Typical values for:


405 nm: 5%

488 nm: 5%

543 nm: 80%

633 nm: 50%

(These values can be changed later during image optimization.)



2


Choose the main beam splitter (HFT).

This reflects laser light to the sample, whereas the emission light will pass through on its way back.

The wavelength of the laser light needs to be represented in the beam splitter.

Ex: Using 405 laser → 405 needs to be present.

A TIP: If you want to set up more than one track (color), pick the HFT that also reflects the lasers you plan to use in the next tracks.




3

Choose the beam splitters to direct the emission light to the correct emission filter and detector. At this point you need to know where to detect the signal.


This is decided based on the emission filters in front of the detector.

For regular imaging Ch2 and Ch3 are the most frequently used.

In general Ch2 can be used for blue and green, Ch3 can be used for green, red, and far red (see next page).



If all the light can go towards Ch2 & 3 use a mirror.



The NFT can also be picked to fit all planned tracks (colors).

In this case blue emission needs to be directed towards Ch2. All NFTs incl. the mirror would be ok for this. But planning ahead NFT 490 is best suited (more page 10).

NFT 490 means that all light below 490 nm is reflected up, everything above 490 passes through.



4

Emission filters are either Band Pass (BP) or Long Pass (LP) filters.

Ex. BP420-480 means that the light between 420-480 passes through to the detector.

LP420 means that everything above 420 passes to the detector.

When you have decided which emission filter to use and thereby the detector, go back and check that the 2nd beam splitter will direct the correct part of the light towards the detector.



Setting up for blue emission:
 Use BP420-480.
 (If LP420 is chosen you risk including emission from any autofluorescence excited with the 405 laser, or any emission from cross excitation of another stain present in the sample.)


Setting up for green emission:
 If you plan to use a red stain in addition : Use BP505-530 or BP505-550 (preferably the last; to include as much of the green emission as possible).
 If only green: LP505 may be used.

Setting up for red emission:
 If you plan to use a far red stain in addition: Use BP560-615
 If red is the last color: Use LP560.

On the schemes below each color has it's own track with the corresponding settings.
Be aware that the path in front of the emission filters is kept the same for all settings.

Ch3 is chosen for green because of the emission filter BP505-550 in front (not present in front of Ch2).
Both green and red can go to detector Ch3, as we are doing sequential scanning of each color at the time.

NFT490 fits all settings because light below 490 is reflected towards Ch2, and the blue emission is filtered between 420 and 480. Light above 490 passes to Ch3 and for green emission, light between 505-550 is filtered. In the red setting emission light is filtered through LP560 which also works fine with NFT490.




4. Adjusting the pinhole

Go to the Scan control window in Channels.

Define **airy unit 1** for the *green channel* and copy the **pinhole diameter** into the blue and red channel.



The airy unit will now slightly differ between the different colors, but the thickness of the optical slice will theoretically be the same.



Optical slices thickness with airy unit at 1 for all pinholes → thickness vary between colors.

Optical slices thickness with the same diameter for all pinholes → thickness between colors is the same.



The green channel is chosen as a reference because it's the channel in the middle and will represent a mean value for the pinhole diameter.



OBS!
If you change the objective pinholes must be adjusted again.

5. Optimization and acquisition of a multicolored image.

For optimizing the image you work between Channels and Mode in the Scan Control window. Optimization has to be done for each Channel (color).




The optimization procedure step by step:



(see more details in the following pages)

- 1) Activate only one channel at the time in Configuration Control. Start with the color that frames what you are interested in in the sample.
- 2) Go to Scan Control Mode. Make a starting image with low zoom (detector gain for the first image can be found with the button Find).
- 3) Define the zoom. Use the Crop button on the side of the image. If you want to be consequent and use the same zoom between images type in the zoom factor.
- 4) Optimize the frame size. This will give the correct numbers of pixels for acquiring the image with optimal resolution (dependent of chosen zoom and the objective used).
- 5) Adjust the scan speed by setting the pixel time to a value between 1,5 and 2,5 μsec .
- 6) Put on the range indicator, which is found under the button Palette on the side of the image. Saturated pixels appear red and pixels below zero are blue.
- 7) Go to Channels and fine adjust the signal in the image by adjusting Detector gain and/or Laser intensity then Amplifier offset while scanning continuously over the sample. *Never use the FastXY-button, always the Cont button.* Increasing gain and laser intensity increases the signal, but first adjust the gain and when this is around 800, the laser should be increased instead. Increasing amplifier offset decreases blue pixels in the image.
- 8) Adjust to avoid red and blue pixels in the image.
- 9) Do the same with the next Channels (colors), point 2-5 will be remembered by the software so you only have to do adjustments in the Channel window.
- 10) With all channels optimized, activate them all in the Configuration Control.
- 11) Go to mode and define averaging, 4 is common to use (in Z-stacks 2).
- 12) Press the single button and the final images are acquired.



1) Activate only one Channel at the time.




2) Begin with a starting image with low zoom, 0.7 will give you the largest possible image on the screen.



3) Define the crop. If you want to always keep the same zoom factor, it can be typed in.






4) After defining the zoom press Optimal under Frame Size. This will define how many pixels you need for optimal resolution for the chosen zoom (and objective).


Be aware that the optimal resolution for different colors will vary. So always optimize with the same color in different images.

When combining the colors blue, green and red, *green will again give the mean value and should be used when optimizing.*

5) Adjust the scan speed. The pixels time should be somewhere between 1,5 and 2,5 µsec. Going too slow will take too much time and might bleach the sample. Going too fast will not give a nice signal.

6) Put on range indicator found under the Palette on the side of the image.





7) For fine adjusting the signal in the image use detector gain and amplifier offset while scanning continuously over the sample.

It's crucial to use the **Cont** button *not the FastXY*.

FastXY is only used when focusing the sample.


Increasing the gain increases the detectors amplification of the photons from the emission → the image becomes brighter.

Increasing the laser intensity on the sample increases the excitation creating more initial emitted photons.

Always exploit the detector range before increasing laser (avoiding bleaching). But at **detector gain around 800** laser may be increased.

The images are generally optimal when there is little red in it.

In the end set the amplifier offset to a level where only a very few blue pixels in the background is visible.




8) The intensity adjustments done is to create an image with grey levels within the dynamic range of 256 (8 bit image). Each pixel in the image ideally should have a grey scale value of 0 to 256.

Red & blue pixels will not have any quantitative value.


But when adjusting the intensities you have to consider what is important in your particular image. If the weaker signal is what you're interested in you might need to saturate other parts of the image.

This is an evaluation up to you!


The background should be kept around zero (very few blue pixels) to avoid hiding any weak signal below the dynamic range.



Highly saturated





No saturation



9) Do similar adjustments on the following channels (colors).

Everything in the Mode window is remembered by the software (zoom, frame size, scan speed).

You only have to optimize the intensities in the image.



Finally after optimizing all colors separately:

10) Activate all tracks under Configuration Control.



11) Go to Mode and define scan average. 4 is common to use. 2 when doing z-stacks.


Doing 4 will acquire the image 4 times, and the result will be a mean image from those 4.

In line mode each line in the image is scanned 4 times and averaged. Mode Frame will average the image frame by frame.

Averaging creates a nicer image and reduces background noise.


12) Press single and the final image is acquired.





The *range indicator* can now be changed to *no palette* and the different colored images are created sequentially. The result is 3 single images and one overlay in the same file.

At the bottom of the image the total and remaining acquisition time comes up.





6. Acquisition of a Z-stack.

Z-stack step by step:


(more details next pages)

- 1) Always start by optimizing each color separately like shown in chapter 5. **But be aware:** Optimize each color in the brightest optical slice (focal plane). This might not be the same plane for all colors. For each color focus with FastXY through the stack and stop at the brightest focal plane and optimize.
- 2) Activate only one color when defining the stack. Use the one that frames what you're interested in.
- 3) Activate Z-stack in Scan Control and chose Mark First/Last.
- 4) Define the borders of the Z-stack. Scan FastXY and focus to one end of the stack and Mark First, then go back into the sample to the next border and Mark Last.
- 5) Go to Z Slice and click Optimal Interval to define the total number of optical slices through the stack.
- 6) Go to Mode and define averaging to 2 (optional).
- 7) Start the scan. The time it takes will come up under the image.

- 1) Optimize the different colors.
- 2) Activate the main channel (color) of interest.
- 3) Activate Z stack.
- 4) Choose Mark First/Last.
- 5) Focus with FastXY to one border of the sample, stop when the fluorescence is getting dim and Mark First.
- 6) Then go back through the sample and decide on the other border Mark Last. Total Z-stack depth comes up.
- 7) Click on Z Slice and choose Optimal Interval. The optical slices will the overlap 50%.



NB! You do not *have to* optimize the interval, this will only ensure the best resolution for a potential 3D reconstruction. You may define fewer slices just to get an overview in different focal planes in the sample.





↑ Remaining and total Z-stack acquiring time.

The progression of the Z-stack may be viewed in Gallery, and if you see that the images contains no more information, the scan can be stopped any time.


7. Saving the images

- 1) Press Save as on the image.
- 2) When saving the first time you have to define the database (MDB) where the images should be saved. A database per date you work may be a way to organize the databases. Choose New MDB and define where to save it. We encourage all to save on our external server Biomic on 'skule'. (For this you need access to the server, for more info contact MIC personnel or Torstein Ravnskog.) You may also open an existing MDB.
- 3) Then enter the name of the image.
- 4) The next image to be saved will automatically be saved in the previous defined database (coming up in blue).
- 5) All images will have the file format .ism and can only be read in LSM software or processing software that reads lsm-files (like Imaris, ImageJ etc.). *A free Zeiss LSM browser can be download; go to the MIC webpage, then to Equipment and Zeiss LSM 510 META. At the bottom of the page you'll find the link.*
- 6) You can export images to all common file formats, but **never delete the raw data files!**



The MDB comes up with raw data information in a form.
The gallery will show all the images in database.

The Reuse button will help you load all the parameters used for that particular image into the acquiring software (except the objective used).




8. Setting up for DIC (transmission) imaging.

DIC (Differential Interference Imaging) step by step:

(more details on the next pages)

- 1) If you want to do a multicolored image with DIC do everything as described in chapter 3 and the proceed with the following steps.
- 2) Adjust the Köhler Illumination on the microscope.
- 3) Choose the DIC filter in the condenser in the Microscope control window. For air objectives DICII, for immersion objectives DICIII.
- 4) The DIC channel can be set up in any track in combination with any other emission Channel and laser. Activate channel D (ChD) and inactivate the current Ch (detector) in the setup.
- 5) Press Find to find the detector gain.
- 6) Use FastXY to find the best focus for DIC.
- 7) Fine adjust the gain and offset to visually get the best DIC image.
- 8) Activate the other Channel in the current setup.

2) Adjusting the Köhler illumination – Essential for acquiring a nice DIC image!!





1. Close the felt blender until you see the polygon and focus this with the vertical adjustments screws. If the polygon is not visible to begin with focus the condenser until you see it.



2. Center the polygon with the centering screws.

3. Open the felt blender like this and fine adjust the centering.

4. Open the felt blender until you see the full view field.



- 3) Choose a DIC filter in the Condenser (for air objectives DICII, for immersion objectives DICIII).
- 4) Activate the transmission detector ChD and inactivate the current emission channel (in the example Ch2 for Blue emission).
- 5) Do a Find for getting a detector gain.
- 6) Fine adjust focus with FastXY if necessary.
- 7) Fine adjust detector gain and offset if necessary.




8) Finally activate the all the different tracks and channels (colors), choose averaging in Mode and do a Single.

Notice that the DIC image is in this example in the track for blue. This means that the DIC image comes up simultaneously with the blue image, and is created with the 405 nm laser.

The DIC image could in principle have been put in any of the tracks.

The DIC image comes as a separate image and in the overlay image in the lsm file.



A DIC image can be acquired alone and later copied into the colored images. But be aware that copying will only work if the images to be copied together has exactly the same frame format.

9. Time series

Doing live cell imaging there are several considerations. Mainly one has to keep the cells happy during the acquisition of the time series.

Before acquiring you need to warm up the heating chamber, ideally a couple of hours before imaging to stabilize the system. Turn on the Temperature Control and the Heater.


When placing the cells under the microscope, make sure to use the right insert. If you need CO₂ put on the CO₂-lid on top of the stage and switch on the CO₂-controller (switch on the back of the control box). This is previously set to give approx. 5 % CO₂ at the sample.

It's a good idea to let the cells acclimatize for some time and to watch the potential focus drift in the beginning of a time lapse.

The settings has to be defined ahead of starting the time series *more or less as described in chapter 3*, but to keep cells happy over time you most likely need to make a compromise on image quality and thereby not necessarily use optimal frame size. Perhaps you also need to increase the pixel time below the recommended 1,5 µsec.

It's is always a good idea to minimize laser intensity on the sample, and to be able to do that opening the pinhole to let more light come to the detector is an option, but this will be a compromise on resolution in Z.

When you're satisfied with the settings for acquisition open Time Series Control.





Define how many images the time series will consist of in Stop series, which means stop series after the number of scans chosen.

Choose the Cycle Delay, the time between images (singled or multi-colored) or eventually Z-stacks.

Start the time series.

Follow the focus over some time. If focus drifts stop the scan, refocus and start the time series over again.



You may follow the time series coming up in the gallery. You can stop the scan any time.

Countdown until next image in the time series.